LOWER & CO.

Harness Size Guide

Measure your dog before ordering to help achieve a secure, comfortable fit.

How to measure

1. Neck girth	Measure around the base of the neck where the harness will sit. Keep the tape snug, not tight.
2. Chest girth	Measure around the widest part of the chest, just behind the front legs. This is the most important measurement.

Harness size chart

Size	Webbing width	Neck girth	Chest girth
XS	2.0 cm	25-30 cm	40-46 cm
S	2.0 cm	33-40 cm	46-58 cm
M	2.0 cm	40-46 cm	54-70 cm
L	2.5 cm	45-62 cm	62-80 cm
XL	2.5 cm	59-67 cm	75-97 cm

Fit tips

• Use a soft measuring tape and measure while your dog is standing naturally.

• Allow enough room to comfortably slide two fingers between the harness and your dog.

• If measurements sit between sizes, use the chest measurement as the main guide and choose the safest adjustment range.

• Check the fit again after adjustment and before longer walks.

Important: Breed and weight alone are not reliable ways to select a harness size. Always measure your dog.

Lower & Co. - Adventure Together.
Sizing based on the current harness specification supplied for the Lower & Co. range.